
INSTALLATION INSTRUCTIONS



E1 and G1 Racks Doors

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.




WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.

CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.


A

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.


LEGEND



TOOLS REQUIRED FOR INSTALLATION



PARTS



INSTALLATION

IMPORTANT!: If the door is to be attached with the pullring handle on the right side, the nut and grounding wire already installed on the door must be removed and reinstalled on the opposite end of the door before the door is installed. The grounding wire should be on the **BOTTOM** of the installed door. (See Figure 1)




Figure 1

 Pull down on upper spring handle, and push up on lower spring handle. (See Figure 2)




Figure 2

2. Insert door into rack, aligning the spring handle ends with the holes at top and bottom of rack. (See Figure 3)




Figure 3

Push spring handle end into rack, and re-latch spring handle.

- 4. Remove and save nut from the grounding lug on rack side rail. (See Figure 4)
- 5. Attach grounding wire from door to the grounding lug. (See Figure 4)
- 6. Replace and tighten nut onto grounding lug. (See Figure 4)




Figure 4




Figure 5



DANGER: IMPROPER WIRING CAN LEAD TO DEATH OR SEVERE PERSONAL INJURY! Grounding must be installed by qualified personnel using a UL Recognized No. 12AWG Green and Yellow grounding wire connected to grounding lug on rack.



Our Mounts. Your Vision.

Chief, a products division of Milestone AV Technologies

8800-002917 Rev00 ©2016 Milestone AV Technologies www.milestone.com 12/16

Europe

USA/International A 6436 City West Parkway, Eden Prairie, MN 55344

800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

Franklinstraat 14, 6003 DK Weert, Netherlands

+31 (0) 495 580 852

+31 (0) 495 580 845

Asia Pacific

A Office No. 918 on 9/F, Shatin Galleria 18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

852 2145 4099

F 852 2145 4477

