

INSTALLATION INSTRUCTIONS



Column-mounted Tablet Floor Stand

DISCLAIMER

Legrand | AV and its affiliated corporations and subsidiaries (collectively "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Legrand AV Inc.

DEFINITIONS

MOUNTING SYSTEM: A MOUNTING SYSTEM is the primary Chief product to which an accessory and/or component is attached.

ACCESSORY: AN ACCESSORY is the secondary Chief product which is attached to a primary Chief product, and may have a component attached or setting on it.

COMPONENT: A COMPONENT is an audiovisual item designed to be attached or resting on an accessory or mounting system such as a video camera, CPU, screen, display, projector, etc.



WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



IMPORTANT SAFETY INSTRUCTIONS



WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all mounting systems are properly assembled and installed using the instructions provided.




WARNING: Failure to provide adequate structural strength for this mounting system can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this mounting system is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the mounting system.



WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components and accessories attached to mounting system does not exceed 10 lbs (4.5 kg) for the main interface or 18 lbs (8.1 kg) for the entire mount when used with both compatible accessories (not included). See Figure below for details.

NOTE: Both accessories shown may be used together.



WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.



WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.




WARNING: Do not use this mounting system outdoors.















WARNING: RISK OF INJURY TO PERSONS! Do not use this mounting system to support video equipment such as televisions or computer monitors.

--SAVE THESE INSTRUCTIONS--


DIMENSIONS




LEGEND

	Tighten Fastener Apretar elemento de fijación Befestigungsteil festziehen Apertar fixador Serrare il fissaggio Bevestiging vastdraaien Serrez les fixations		Pencil Mark Marcar con lápiz Stiftmarkierung Marcar com lápis Segno a matita Potloodmerkteken Marquage au crayon
	Loosen Fastener Aflojar elemento de fijación Befestigungsteil lösen Desapertar fixador Allentare il fissaggio Bevestiging losdraaien Desserrez les fixations		Drill Hole Perforar Bohrloch Fazer furo Praticare un foro Gat boren Percez un trou
	Phillips Screwdriver Destornillador Phillips Kreuzschlitzschraubendreher Chave de fendas Phillips Cacciavite a stella Kruiskopschroevendraaier Tournevis à pointe cruciforme		Adjust Ajustar Einstellen Ajustar Regolare Afstellen Ajuster
	Open-Ended Wrench Llave de boca Gabelschlüssel Chave de bocas Chiave a punte aperte Steeksleutel Clé à fourche		Remove Quitar Entfernen Remover Rimuovere Verwijderen Retirez
	By Hand A mano Von Hand Com a mão A mano Met de hand À la main		Optional Opcional Optional Opcional Opzionale Optie En option
	Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada Chiave esagonale Zeskantsleutel Clé à tête hexagonale		Security Wrench Llave de seguridad Sicherheitsschlüssel Chave de segurança Chiave di sicurezza Veiligheidssleutel Clé de sécurité

TOOLS REQUIRED FOR INSTALLATION



PARTS



Assembly And Installation

1. Partially install six #10-24 x 5/8" button head cap screws (E) into column (A). (See Figure 1)




Figure 1

2. Install bolt plate (C) inside column (A) channel. (See Figure 2)
3. Use four #10-24 x 1/2" flat head cap screws (F) to secure two base plates (D) to column (A) and bolt plate (C). (See Figure 2)




Figure 2



WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components and accessories attached to mounting system does not exceed 10 lbs (4.5 kg) for the main interface or 18 lbs (8.1 kg) for the entire mount when used with both compatible accessories (not included). See Figure on page 2 for details.

4. Use column-mounted tablet nut (provided with column-mounted tablet) to install column-mounted tablet (not included) to column. (See Figure 3)




Figure 3

5. Connect cord to bottom of column-mounted tablet. (See Figure 4)
6. Install column cover (B) onto column (A) making sure keyholes are onto screws and cable is routed through the bottom gap on cover. (See Figure 4)
7. Tighten all screws (F) to secure cover (B) to column (A). (See Figure 4)




Figure 4

Cable Management

1. Loosen screws (E) holding cover (B) to column (A) and remove cover (B). (See Figure 5)
2. Route component cable(s) using middle and lower openings on cover (B). (See Figure 5)
3. Reinstall cover (B) and tighten screws (E) to secure cover (B) to column (A). (See Figure 5)




Figure 5

Bolt to Floor (Optional)

The HFSTS mount may be bolted to the floor for increased security or stability. Hardware is NOT provided for this installation.

IMPORTANT ! : Base plates (D) must be attached to column (A) and bolt plate (C) before being bolted to floor.

1. Use base plates (D) as a template to mark holes on floor at desired mounting location.
2. Drill holes at marked locations according to instructions of hardware being used for installation. (See Figure 6)
3. Use hardware (not included) to secure base plates (D) to floor. (See Figure 6)




Figure 6



8800-003237 Rev01
©2020 Legrand | AV
www.legrandav.com
09/2020

USA/International	A 6436 City West Parkway, Eden Prairie, MN 55344 P 800.582.6480 / 952.225.6000 F 877.894.6918 / 952.894.6918
Europe	A Franklinstraat 14, 6003 DK Weert, Netherlands P +31 (0) 495 580 852 F +31 (0) 495 580 845
Asia Pacific	A Office No. 918 on 9/F, Shatin Galleria 18-24 Shan Mei Street Fotan, Shatin, Hong Kong P 852 2145 4099 F 852 2145 4477

