

INSTRUCTIONS FOR

Display Easel



How To Set Up Easel

Unfold all three legs. Their self-locking hinges will hold them rigid. Spread outside legs as far as possible. Push notched support bar down into locked position.

The Quick Grip Chart Clamp

Fits on the easel by hooking the brackets on the clamp over the edge of the head of the easel. To lock the clamp to the easel head, move the blue spring device located on the back of the head to the upright position. The bullet on the spring should then go into the hole on the back on the chart clamp. This clamp is for use with flip charts and also serves as a support for large charts on displays.

How To Fold Easel

Push in hinge release attached to each leg. Fold up each leg until it snaps onto the top portion of the leg. Push notched arm up and fold easel together.



A BRAND OF MILESTONE AV TECHNOLOGIES | www.milestone.com

P 800.622.3737 / 574.267.8101 F 877.325.4832 / 574.267.7804

E info@da-lite.com

In British Columbia, Milestone AV Technologies ULC carries on business as MAVT Milestone AV Technologies ULC.

©2017 Milestone AV Technologies. DL-0333 (Rev. 1) 09:14.

Da-Lite is a registered trademarks of Milestone AV Technologies. All other brand names or marks are used for identification purposes and are trademarks of their respective owners. All patents are protected under existing designations. Other patents pending.