

# INSTALLATION INSTRUCTIONS

## ADDENDUM TO XPD1U/XFD1U Carts/Stands

**IMPORTANT !** : The following steps may be taken to relocate the control pad from the side of the cart/stand to underneath the display using double-sided tape. Disregard this addendum if the control pad is not going to be relocated.

1. Remove front or rear cover from cart/stand. See XPD1U/XFD1U installation instructions for details.
2. Unplug control pad cable from the RJ45 port in the control box.
3. Remove cable through side cable cover.
4. Pull cable out through opening at bottom of cable cover.
5. Feed removed cable down through center channel.
6. Plug cable back into control box.
7. Use double-sided foam tape (included) to attach control pad to bottom of display in the center.
8. Re-install front or rear cover to cart/stand. See XPD1U/XFD1U installation instructions for details.




Figure 1

Legrand | AV, and its affiliated corporations and subsidiaries (collectively, "Legrand | AV"), intend to make this manual accurate and complete. However, Legrand | AV makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Legrand | AV makes no representation of warranty, expressed or implied, regarding the information contained herein. Legrand | AV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.



A brand of **Legrand**

Chief Manufacturing, a products division of Legrand AV Technologies  
6436 City West Parkway, Eden Prairie, MN 55344

• P: 800.582.6480 / 952.225.6000 • F: 877.894.6918 / 952.894.6918

8800-003138 Rev01  
©2019 Legrand AV Technologies

04/19