
# INSTALLATION INSTRUCTIONS



**Stackable Racks** 



NS2F1520-2020

#### **DISCLAIMER**

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



#### IMPORTANT SAFETY INSTRUCTIONS

**WARNING:** A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



**CAUTION:** A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



**WARNING:** Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.



WARNING: Failure to provide adequate structural strength for this component can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the structure to which this component is attached can support five times the combined weight of all equipment. Reinforce the structure as required before installing the component.



WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located within the rack does not exceed 600 lbs (272 kg) if rack is free-standing or stacked or 200 lbs (90.7 kg) if mounted to a wall. Use with products heavier than the maximum weight indicated may result in instability or collapse of the rack causing possible injury.



**WARNING:** Do NOT stack more than two rack assemblies on top of each other.



**CAUTION:** If free standing, always load the rack from the bottom up and load the heaviest item in the rack first to prevent tipping. If mounted to a wall, weight can be distributed as desired.



**CAUTION:** If free standing, 50% of the total weight should be mounted in the lower third of the rack.

**IMPORTANT!**: Minimum spacings between the Accessories and components and the (ITC/AV) Rack Enclosure shall be maintained for safe operation of the equipment when installed in accordance with the National Electric Code, ANSI/NFPA 70-2008. Operating temperature inside rack shall not exceed 104°F.



**WARNING:** Do not use this product outdoors.





**WARNING:** RISK OF INJURY TO PERSONS! Do not use this mounting system to support video equipment such as televisions or computer monitors.

**IMPORTANT!**: NS2F1520-2020 racks are designed to be mounted to an 8" concrete, 8"x8"x16" concrete block, or 2" x 4" wood studs (16" on center) wall.

#### --SAVE THESE INSTRUCTIONS--

#### **DIMENSIONS**







#### **LEGEND**

	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
680	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
	Clé à tête hexagonale	Clé de sécurité

#### **TOOLS REQUIRED FOR INSTALLATION**



#### **PARTS**



#### **Assembly And Installation**

#### **Frame Construction**

- Position brace (C) over screw studs on left frame (A). (See Figure 1)
- 2. Thread two 1/4-20 hex nuts (F) over vertical screw studs to secure brace (C) to left frame (A). (See Figure 1)
- 3. Thread 1/4-20 hex nut (F) over horizontal screw stud to secure brace (C) to left frame (A). (See Figure 1)




Figure 1

 Repeat steps 1-3 to secure right frame (B) to brace (C). (See Figure 2)




Figure 2

- Position second brace (C) over upper screw studs on left and right frames (A and B). (See Figure 3)
- Thread four 1/4-20 hex nuts (F) over vertical studs to secure brace (C) to left and right frames (A and B). (See Figure 3)
- Thread two 1/4-20 hex nuts (F) over horizontal screw studs to secure brace to right and left frames (A and B). (See Figure 3)




Figure 3

8. Use eight #10-32 x 3/4" Phillips machine screws (G) to secure two front panels (D) to frames (A and B). (See Figure 4)




Figure 4

### **Install Feet (Optional)**

- 1. Lay assembled frame on its back. (See Figure 5)
- Thread four feet (E) into holes on bottom of frames. (See Figure 5)




Figure 5

Use a flathead screwdriver to turn each screw until rack is completely level. (See Figure 6)




Figure 6

 Tighten nuts on feet until they are flush with the bottom of the rack. (See Figure 7)




Figure 7

### **Stacking (Second Rack sold separately)**

 Place assembled second rack (without feet) onto first rack. (See Figure 8)




Figure 8

 Use four 1/4-20 x 3/8" Phillips screws (H) to secure second rack to first rack. (See Figure 9)

WARNING: Do NOT stack more than two racks on top of each other!




Figure 9

#### **Mounting Single Rack to Wall - Wood Studs**

NOTE: If installing to Concrete/Concrete Block, proceed to Mounting to Concrete/Concrete Block Section. If installing a Stacked Rack, proceed to Mounting Stacked Rack Sections.

- 1. Use a stud finder to locate wood studs.
- Place assembled frame over studs and mark hole locations. (See Figure 10)

**IMPORTANT!:** Use a level to make sure of a level mount.

3. Drill four 7/32" (5.5mm) diameter holes to a depth of 3 1/2" (89mm) at marked locations. (See Figure 10)




Figure 10

- Partially install two 5/16" x 3 1/2" lag bolts (M) into upper holes. (See Figure 11)
- 5. Hang rack onto partially installed bolts. (See Figure 11)




Figure 11

- 6. Slide two "U" washers (J) onto lag bolts (M). (See Figure 12)
- 7. Tighten two lag bolts (M) until "U" washers (J) are pulled firmly against the brace. (See Figure 12)




Figure 12

8. Use two 5/16" x 3 1/2" lag bolts (M) and two 3/4" spacers (K) to secure lower part of bracket to wall. (See Figure 13)




Figure 13

# Mounting Single Rack to Wall - Concrete or Concrete Block

- 1. Determine mounting location.
- Place assembled frame on wall and mark hole locations. (See Figure 14)

**IMPORTANT!**: Use a level to make sure of a level mount.

3. Drill four 3/8" (10mm) diameter holes to a depth of 3 1/2" (89mm) at marked locations. (See Figure 14)




Figure 14

4. Install four U10 anchors (L) into drilled holes. (See Figure 15)




Figure 15

- Partially install two 5/16" x 3 1/2" lag bolts (M) into upper U10 anchors (L). (See Figure 16)
- 6. Hang rack onto partially installed bolts. (See Figure 16)




Figure 16

- 7. Slide two "U" washers (J) onto lag bolts (M). (See Figure 17)
- 8. Tighten two lag bolts (M) until "U" washers are pulled firmly against the brace. (See Figure 17)




Figure 17

9. Use two 5/16" x 3 1/2" lag bolts (M) and two 3/4" spacers (K) to secure lower part of rack to wall. (See Figure 18)




Figure 18

## Mounting Stacked Racks to Wall- Wood Studs

- Use a stud finder to locate wood studs.
- Place assembled frame over studs and mark eight hole locations.

**IMPORTANT!**: Use a level to make sure of a level mount.

- 3. Drill eight 7/32" (5.5mm) diameter holes to a depth of 3 1/2" (89mm) are marked locations.
- 4. Partially install two 5/16" x 3 1/2" lag bolts (M) into upper holes. (See Figure 19)
- 5. Hang rack onto bolts. (See Figure 19)




Figure 19

- 6. Slide two "U" washers (J) onto lag bolts (M). (See Figure 20)
- 7. Tighten two lag bolts (M) until "U" washers are pulled firmly against the brace. (See Figure 20)
- 8. Use two 5/16" x 3 1/2" lag bolts (M) and two 3/4" spacers (K) to secure lower part of rack to wall. (See Figure 20)
- 9. Repeat Steps 4 and 6-9 for lower rack.




Figure 20

## Mounting Stacked Racks to Wall - Concrete or Concrete Block

 Determine mounting location and place assembled frame on wall and mark hole locations.

**IMPORTANT!:** Use a level to make sure of a level mount.

- Drill eight 3/8" (10mm) diameter holes to a depth of 3 1/2" (89mm) are marked locations.
- Install eight U10 anchors (L) into drilled holes. (See Figure 21)




Figure 21

- 4. Partially install two 5/16" x 3 1/2" lag bolts (M) into upper holes. (See Figure 22)
- 5. Hang rack onto bolts. (See Figure 22)




Figure 22

- 6. Slide two "U" washers (J) onto lag bolts (M). (See Figure 20)
- Tighten two lag bolts (M) until "U" washers are pulled firmly against the brace. (See Figure 20)
- 3. Use two 5/16" x 3 1/2" lag bolts (M) and two 3/4" spacers (K) to secure lower part of rack to wall. (See Figure 20)
- Repeat Steps 4 and 6-9 for lower rack.



Chief, a products division of Milestone AV Technologies

8800-002707 Rev00 ©2015 Milestone AV Technologies www.chiefmfg.com 02/15 USA/International A 6436 City West Parkway, Eden Prairie, MN 55344

**Europe** 

**P** 800.582.6480 / 952.225.6000

**F** 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

**P** +31 (0) 495 580 852

F +31 (0) 495 580 845

Asia Pacific A Office No. 918 on 9/F, Shatin Galleria

18-24 Shan Mei Street Fotan, Shatin, Hong Kong

**P** 852 2145 4099

852 2145 4477

